



# GUIDE

Class 5 SmartMotor™ Technology



# Copyright Notice

©2012-2014, Moog Inc., Animatics.

Moog Animatics Class 5 SmartMotor™ PROFIBUS Guide, Rev. A, PN: SC80100009-001.

This manual, as well as the software described in it, is furnished under license and may be used or copied only in accordance with the terms of such license. The content of this manual is furnished for informational use only, is subject to change without notice and should not be construed as a commitment by Moog Inc., Animatics. Moog Inc., Animatics assumes no responsibility or liability for any errors or inaccuracies that may appear herein.

Except as permitted by such license, no part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form or by any means, electronic, mechanical, recording, or otherwise, without the prior written permission of Moog Inc., Animatics.

The programs and code samples in this manual are provided for example purposes only. It is the user's responsibility to decide if a particular code sample or program applies to the application being developed and to adjust the values to fit that application.

Moog Animatics and the Moog Animatics logo, SmartMotor and the SmartMotor logo, Combitronic and the Combitronic logo are all trademarks of Moog Inc., Animatics.

Please let us know if you find any errors or omissions in this manual so that we can improve it for future readers. Such notifications should contain the words "PROFIBUS Guide" in the subject line and be sent by e-mail to: [techwriter@moog.animatics.com](mailto:techwriter@moog.animatics.com). Thank you in advance for your contribution.

Contact Us:

Moog Inc., Animatics  
1421 McCarthy Boulevard  
Milpitas, CA 95035  
USA

Tel: 1 (408) 965-3320  
Fax: 1 (408) 965-3319  
Support: 1 (888) 356-0357

[www.animatics.com](http://www.animatics.com)

---

# Table of Contents

<b>Introduction</b>	<b>7</b>
Purpose	8
PROFIBUS Overview	8
PROFIBUS Features	9
Equipment Required	10
Hardware	10
Software	10
Safety Information	11
Safety Symbols	11
Other Safety Considerations	11
Safety Information Resources	13
Additional Documents	14
Additional Resources	15
<b>PROFIBUS Motor Pinouts, Connections and Status LEDs</b>	<b>17</b>
PROFIBUS Motor Connectors and Pinouts	18
D-Style Motor PROFIBUS Connector and Pinouts	18
Other D-Style Motor Connectors and Pinouts	18
Cables and Diagram	19
PROFIBUS Cables and Connectors	19
PROFIBUS Cable Diagram	20
Cable Length	21
PROFIBUS Status LEDs	22
<b>PROFIBUS Configuration</b>	<b>23</b>
Configure Motor with PC	24
User Program Requirements	24
Required Nonvolatile EEPROM Values	24
Reserved Motor Variables	25
Configure PLC with PC	25
Configure SmartMotor to PROFIBUS	25

---

PLC Sends Commands to Motor .....	25
Network Data Format Example .....	26
PLC Memory .....	27
Sequence to Set Report Data to Motor Clock .....	28
PROFIBUS Communication Example .....	29
<b>Sample Command Sequences .....</b>	<b>33</b>
Overview .....	34
Command and Response Codes .....	34
Handshaking of Messages .....	34
Disabling Limits from Preventing Motion .....	34
Turning the Motor Shaft .....	34
Disable Limits and Clear Fault Status .....	35
Commands .....	35
PLC Memory .....	35
Disable positive limit, command EIGN(2) .....	35
Disable negative limit, command EIGN(3) .....	36
Clear fault status, command ZS .....	36
Initiate Mode Torque .....	37
Commands .....	37
PLC Memory .....	37
Set torque value, specify the response data .....	37
Initiate torque mode, command MT .....	37
Initiate Relative Position Move .....	39
Commands .....	39
PLC Memory .....	39
Set acceleration value, command ADT=255 .....	39
Set maximum velocity value, command VT=100000 .....	39
Make a relative position move .....	40
<b>Nonvolatile Data .....</b>	<b>43</b>
Program Example .....	44

---

<b>Output and Input Packets .....</b>	<b>45</b>
Output and Input Packet Format .....	46
Command (Output) Packet Notes .....	47
Response (Input) Packet Notes .....	48
<b>Alternate Communications Channel .....</b>	<b>50</b>
Reserved Motor Variables .....	50
<b>Command and Response Codes .....</b>	<b>51</b>
Command Packet Codes to Motor Commands .....	52
Response Packet Codes to Motor Commands .....	60
<b>Troubleshooting .....</b>	<b>66</b>



# Introduction

This chapter provides information on the purpose and scope of this manual. It also provides information on safety notation, related documents and additional resources.

<b>Purpose .....</b>	<b>8</b>
<b>PROFIBUS Overview .....</b>	<b>8</b>
<b>PROFIBUS Features .....</b>	<b>9</b>
<b>Equipment Required .....</b>	<b>10</b>
Hardware .....	10
Software .....	10
<b>Safety Information .....</b>	<b>11</b>
Safety Symbols .....	11
Other Safety Considerations .....	11
Safety Information Resources .....	13
<b>Additional Documents .....</b>	<b>14</b>
<b>Additional Resources .....</b>	<b>15</b>

## Purpose

This manual explains the Moog Animatics Class 5 SmartMotor™ support for the PROFIBUS protocol. It describes the major concepts that must be understood to integrate a SmartMotor slave with a PLC or other PROFIBUS master. However, it does not cover all the low-level details of the PROFIBUS protocol.

**NOTE:** The feature set described in this version of the manual refers to motor firmware 5.32.4.x.

This manual is intended for programmers or system developers who understand the use of PROFIBUS. (PROFIBUS communication is described in IEC61158 Type 3 and IEC61784.) Therefore, this manual is not a tutorial on those specifications or the PROFIBUS protocol. Instead, it should be used to understand the specific implementation details for the Moog Animatics SmartMotor. Additionally, examples are provided for the various modes of motion and accessing those modes through PROFIBUS to operate the SmartMotor.

The Command and Response Code chapter of this manual includes details about the specific commands available in the SmartMotor through the PROFIBUS protocol. The commands include those required by the specification and those added by Moog Animatics. For details, see Command and Response Codes on page 51. Also, see Nonvolatile Data on page 43.

In addition to this manual, it is recommended that you visit the PROFINET/PROFIBUS website (at <http://www.profibus.com>), where you will find documentation, tutorials, and other useful resources.

## PROFIBUS Overview

PROFIBUS is an independent, open fieldbus standard that allows different manufacturers of automation products to communicate without special interface adjustments. Specifically, PROFIBUS, which is optimized for high speed, is designed to communicate between control systems and distributed I/O at the device level.

Moog Animatics has defined a set of 8-bit command and response codes to be transmitted and received over PROFIBUS. For details, see Command Packet Codes to Motor Commands on page 52. These codes generally correspond to Class 5 SmartMotor™ commands. To set target position, for example, the "set target position" command code is transmitted together with the data consisting of the target position value.

The PROFIBUS SmartMotor is a SmartMotor with the addition of the PROFIBUS connectors and interface board, which then accepts commands as a slave over a PROFIBUS network. In addition to communicating over PROFIBUS, SmartMotor commands may be sent through other communication interfaces of the SmartMotor. Depending on the SmartMotor model, it may also communicate over RS-232 or RS-485.

The Moog Animatics communications profile over PROFIBUS is intended to integrate well with a PLC that continuously transmits and receives cyclic data. The command and response codes achieve this through a handshaking mechanism.

Certain configuration data is held in nonvolatile storage in the SmartMotor. Therefore, the motor data EEPROM must be correctly initialized before PROFIBUS operation.

A PROFIBUS Generic Station Description (GSD) configuration file, which is an XML file (also referred to as a "GSDML" file), is necessary for the host to configure the PROFIBUS master and to connect to the slave motor. Make sure you obtain the latest version of the file, which is



available from the Moog Animatics website Download Center. For more details, see Software on page 10.

Document sections include Output and Input data formats (PROFIBUS cargo), a list of the Moog Animatics PROFIBUS command codes explained in terms of the equivalent SmartMotor commands, and a list of Moog Animatics PROFIBUS response codes explained in terms of the equivalent SmartMotor commands.

## PROFIBUS Features

Moog Animatics PROFIBUS features include:

- Command/Response Codes for all Class 5 SmartMotor commands
- Use of onboard I/O via PROFIBUS, SmartMotor program, or RS-232 commands
- Ability to run 1000 SmartMotor subroutines through PROFIBUS
- Ability to read/write all SmartMotor variables
- SmartMotor online diagnostics through SMI software and RS-232 connection
- Up to 127 PROFIBUS nodes
- 250 microsecond interrupt-driven subroutine
- Data rates: 1.5 Mbps (default); 9.6, 19.2, 31.25, 45.45, 93.75, 187.5, 500 Kbps; 1.5, 3, 6, 12 Mbps

**NOTE:** PROFIBUS baud rates are achievable only with proper cable length and termination connectors. The minimum cable length when operating  $\geq 1$  MBaud is 1 meter ( $\sim 3$  feet). If the cable is too short, reflected impedance can cause loss of communication data packets and spurious node errors. For more cabling details, refer to Cables and Diagram on page 19.

## Equipment Required

The section describes the required PROFIBUS hardware and software.

### Hardware

The following hardware is required:

- Moog Animatics PROFIBUS SmartMotor™
- Moog Animatics power supply or user-supplied equivalent
- Moog Animatics RS-232 or RS-485 communications cable that is compatible with the SmartMotor
- User-supplied PC with the Microsoft Windows operating system; for the Class 5 SmartMotor, an RS-232 port is required
- For the Class 5 SmartMotor, Moog Animatics RS-232 to RS-485 converter
- User-supplied PLC with PROFIBUS master or other PROFIBUS master
- Moog Animatics PROFIBUS cable, or equivalent, and connectors with correct terminating resistors

### Software

The following software is required:

- User-supplied PLC configuration software
- Moog Animatics SMI software (latest version), which is available on the Moog Animatics website at:

<http://www.animatics.com/support/download-center.html>

- Moog Animatics PROFIBUS GSDML file, which is available on the Moog Animatics website at:

<http://www.animatics.com/support/download-center.html>

**NOTE:** The PROFIBUS GSD configuration file name will have the form "DEAF070C.GSD". Make sure you obtain the latest version of the file.

PROFIBUS GSD file and firmware combinations:

- SM5\_070C.GSD requires firmware 5.32.4.9 or newer
- Firmware 5.32.4.9 or newer may use DEAF070C.GSD; however, SM5\_070C.GSD is strongly recommended
- Firmware 5.32.4.7 or previous must use DEAF070C.GSD

## Safety Information

This section describes the safety symbols and other safety information.

### Safety Symbols

The manual may use one or more of the following safety symbols:



**WARNING:** This symbol indicates a potentially non-lethal mechanical hazard, where failure to follow the instructions could result in serious injury to the operator or major damage to the equipment.

---



**CAUTION:** This symbol indicates a potential minor hazard, where failure to follow the instructions could result in slight injury to the operator or minor damage to the equipment.

---

**NOTE:** Notes are used to emphasize non-safety concepts or related information.

### Other Safety Considerations

The Moog Animatics SmartMotors are supplied as components that are intended for use in an automated machine or system. As such, it is beyond the scope of this manual to attempt to cover all the safety standards and considerations that are part of the overall machine/system design and manufacturing safety. Therefore, the following information is intended to be used only as a general guideline for the machine/system designer.

It is the responsibility of the machine/system designer to perform a thorough "Risk Assessment" and to ensure that the machine/system and its safeguards comply with the safety standards specified by the governing authority (for example, ISO, OSHA, UL, etc.) for the locale where the machine is being installed and operated. For more details, see Machine Safety on page 12.

#### Motor Sizing

It is the responsibility of the machine/system designer to select SmartMotors that are properly sized for the specific application. Undersized motors may: perform poorly, cause excessive downtime or cause unsafe operating conditions by not being able to handle the loads placed on them. The *Moog Animatics Product Catalog*, which is available on the Moog Animatics website, contains information and equations that can be used for selecting the appropriate motor for the application.

Replacement motors must have the same specifications and firmware version used in the approved and validated system. Specification changes or firmware upgrades require the approval of the system designer and may require another Risk Assessment.

#### Environmental Considerations

It is the responsibility of the machine/system designer to evaluate the intended operating environment for dust, high-humidity or presence of water (for example, a food-processing environment that requires water or steam wash down of equipment), corrosives or chemicals that may come in contact with the machine, etc. Moog Animatics manufactures specialized

IP-rated motors for operating in extreme conditions. For details, see the *Moog Animatics Product Catalog*, which is available on the Moog Animatics website.

## Machine Safety

In order to protect personnel from any safety hazards in the machine or system, the machine/system builder must perform a "Risk Assessment", which is often based on the ISO 13849 standard. The design/implementation of barriers, emergency stop (E-stop) mechanisms and other safeguards will be driven by the Risk Assessment and the safety standards specified by the governing authority (for example, ISO, OSHA, UL, etc.) for the locale where the machine is being installed and operated. The methodology and details of such an assessment are beyond the scope of this manual. However, there are various sources of Risk Assessment information available in print and on the internet.

**NOTE:** The following list is an example of items that would be evaluated when performing the Risk Assessment. Additional items may be required. The safeguards must ensure the safety of all personnel who may come in contact with or be in the vicinity of the machine.

In general, the machine/system safeguards must:

- Provide a barrier to prevent unauthorized entry or access to the machine or system. The barrier must be designed so that personnel cannot reach into any identified danger zones.
- Position the control panel so that it is outside the barrier area but located for an unrestricted view of the moving mechanism. The control panel must include an E-stop mechanism. Buttons that start the machine must be protected from accidental activation.
- Provide E-stop mechanisms located at the control panel and at other points around the perimeter of the barrier that will stop all machine movement when tripped.
- Provide appropriate sensors and interlocks on gates or other points of entry into the protected zone that will stop all machine movement when tripped.
- Ensure that if a portable control/programming device is supplied (for example, a hand-held operator/programmer pendant), the device is equipped with an E-stop mechanism.

**NOTE:** A portable operation/programming device requires *many* additional system design considerations and safeguards beyond those listed in this section. For details, see the safety standards specified by the governing authority (for example, ISO, OSHA, UL, etc.) for the locale where the machine is being installed and operated.

- Prevent contact with moving mechanisms (for example, arms, gears, belts, pulleys, tooling, etc.).
- Prevent contact with a part that is thrown from the machine tooling or other part-handling equipment.
- Prevent contact with any electrical, hydraulic, pneumatic, thermal, chemical or other hazards that may be present at the machine.
- Prevent unauthorized access to wiring and power-supply cabinets, electrical boxes, etc.

- Provide a proper control system, program logic and error checking to ensure the safety of all personnel and equipment (for example, to prevent a run-away condition). The control system must be designed so that it does not automatically restart the machine/system after a power failure.
- Prevent unauthorized access or changes to the control system or software.

## Documentation and Training

It is the responsibility of the machine/system designer to provide documentation on safety, operation, maintenance and programming, along with training for all machine operators, maintenance technicians, programmers, and other personnel who may have access to the machine. This documentation must include proper lockout/tagout procedures for maintenance and programming operations.

It is the responsibility of the operating company to ensure that:

- All operators, maintenance technicians, programmers and other personnel are tested and qualified before acquiring access to the machine or system.
- The above personnel perform their assigned functions in a responsible and safe manner to comply with the procedures in the supplied documentation and the company safety practices.
- The equipment is maintained as described in the documentation and training supplied by the machine/system designer.

## Additional Equipment and Considerations

The Risk Assessment and the operating company's standard safety policies will dictate the need for additional equipment. In general, it is the responsibility of the operating company to ensure that:

- Unauthorized access to the machine is prevented at all times.
- The personnel are supplied with the proper equipment for the environment and their job functions, which may include: safety glasses, hearing protection, safety footwear, smocks or aprons, gloves, hard hats and other protective gear.
- The work area is equipped with proper safety equipment such as first aid equipment, fire suppression equipment, emergency eye wash and full-body wash stations, etc.
- There are no modifications made to the machine or system without proper engineering evaluation for design, safety, reliability, etc., and a Risk Assessment.

## Safety Information Resources

Additional SmartMotor safety information can be found on the Moog Animatics website; open the file "109\_Controls, Warnings and Cautions.pdf" located at:

<http://www.animatics.com/support/moog-animatics-catalog.html>

OSHA standards information can be found at:

<https://www.osha.gov/law-regs.html>

ANSI-RIA robotic safety information can be found at:

<http://www.robotics.org/robotic-content.cfm/Robotics/Safety-Compliance/id/23>

UL standards information can be found at:

<http://www.ul.com/global/eng/pages/solutions/standards/accessstandards/catalogofstandards/>

ISO standards information can be found at:

<http://www.iso.org/iso/home/standards.htm>

EU standards information can be found at:

[http://ec.europa.eu/enterprise/policies/european-standards/harmonised-standards/index\\_en.htm](http://ec.europa.eu/enterprise/policies/european-standards/harmonised-standards/index_en.htm)

## Additional Documents

The Moog Animatics website contains additional documents that are related to the information in this manual. Please refer to the following list:

- *Moog Animatics SmartMotor™ User's Guide*  
<http://www.animatics.com/support/download-center.html>
- *Moog Animatics SmartMotor™ Command Reference Guide*  
<http://www.animatics.com/support/download-center.html>
- *SmartMotor™ Product Certificate of Conformance*  
[http://www.animatics.com/download/Animatics\\_SmartMotor\\_Servida\\_Class\\_5\\_Declaration\\_of\\_Conformity\\_CE\\_Rev\\_1.pdf](http://www.animatics.com/download/Animatics_SmartMotor_Servida_Class_5_Declaration_of_Conformity_CE_Rev_1.pdf)
- *SmartMotor™ UL Certification*  
[http://www.animatics.com/download/MA\\_UL\\_online\\_listing.pdf](http://www.animatics.com/download/MA_UL_online_listing.pdf)
- *SmartMotor Developer's Worksheet*  
(interactive tools to assist developer: Scale Factor Calculator, Status Words, CAN Port Status, Serial Port Status, RMODE Decoder, and Syntax Error Codes)  
<http://www.animatics.com/support/download-center.html>
- *Moog Animatics Product Catalog*  
<http://www.animatics.com/support/moog-animatics-catalog.html>

## Additional Resources

The Moog Animatics website contains additional resources such as product information, documentation, product support and more. Please refer to the following addresses:

- General company information:  
<http://www.animatics.com>
- Product information:  
<http://www.animatics.com/products.html>
- Product support (Downloads, How To videos, Forums, Knowledge Base, and FAQs):  
<http://www.animatics.com/support.html>
- Sales and distributor information:  
<http://www.animatics.com/sales-offices.html>
- Application ideas (including videos and sample programs):  
<http://www.animatics.com/applications.html>

PROFINET and PROFIBUS are common standards maintained by PROFIBUS and PROFINET International (PI):

- PROFIBUS and PROFINET International (PI) website:  
<http://www.profibus.com/>





# PROFIBUS Motor Pinouts, Connections and Status LEDs

The following sections describe the motor pinouts, system connections and the status LEDs.

<b>PROFIBUS Motor Connectors and Pinouts</b> .....	<b>18</b>
D-Style Motor PROFIBUS Connector and Pinouts .....	18
Other D-Style Motor Connectors and Pinouts .....	18
<b>Cables and Diagram</b> .....	<b>19</b>
PROFIBUS Cables and Connectors .....	19
PROFIBUS Cable Diagram .....	20
Cable Length .....	21
<b>PROFIBUS Status LEDs</b> .....	<b>22</b>

# PROFIBUS Motor Connectors and Pinouts

The following figure provides an overview of the PROFIBUS connectors and pinouts available on the Class 5 SmartMotors.


## D-Style Motor PROFIBUS Connector and Pinouts

The following figure shows the location of the PROFIBUS connector on the back of the D-style SmartMotor.



## Other D-Style Motor Connectors and Pinouts

The following figure shows the locations of all connectors and status LEDs that are included on the D-style SmartMotor with the PROFIBUS option.



## Cables and Diagram

This section provides some general information on connecting Moog Animatics PROFIBUS SmartMotors.

**NOTE:** For full details and requirements on PROFIBUS cables and termination procedures, consult the PROFIBUS standards.

### PROFIBUS Cables and Connectors

Moog Animatics does not currently stock or supply PROFIBUS cables or connectors. However, these items are readily available from industrial electronics suppliers.


#### Example PROFIBUS Cable

The following figure shows a cross-section of typical PROFIBUS cable. The conductor wires attach to the A and B terminals on the PROFIBUS connector.



**CAUTION:** Make certain that you always attach the same wire color to the same connector terminal (e.g., green wire to A terminal and red wire to B terminal).

---



*Cross-Section of Shielded PROFIBUS Cable*




**CAUTION:** To minimize the possibility of electromagnetic interference (EMI), all connections should use *shielded* cables.

---

## Example PROFIBUS Connector

The following figure shows an example of a PROFIBUS connector. These connectors allow you to have a cable input and output on one connector for daisy-chaining to other PROFIBUS devices. They also incorporate a termination switch. That switch must be activated (ON) at both ends of the bus. The switch must be deactivated (OFF) for the other devices along the bus.



*Example of PROFIBUS Connectors*

**NOTE:** At least one PROFIBUS connector with a diagnostic/programmer socket is required in each segment. These are for diagnostic and monitoring purposes only. They are not used to stack PROFIBUS connectors.

## PROFIBUS Cable Diagram

The following figure shows an in-line (daisy chain) network topology. For PROFIBUS network design and installation details, see the information available at:

<http://www.profibus.com>


The following diagram shows an example PROFIBUS network with the SmartMotors daisy chained to the master device.



**CAUTION:** PROFIBUS *requires* terminators at each end of the network bus.

---

## PROFIBUS Cable Diagram



**NOTE:** The "incoming" cable connection must be used on the first and last connector of the system. Otherwise, the terminator switch will disconnect the device if it is wired to the "outgoing" connection.

**NOTE:** At least one PROFIBUS connector with a diagnostic/programmer socket is required in each segment. These are for diagnostic and monitoring purposes only. They are not used to stack PROFIBUS connectors.


### Cable Length

The PROFIBUS transmission speed determines the cable length. As noted previously, the minimum cable length when operating  $\geq 1$  Mbaud (or 1 Mbps) is 1 meter ( $\sim 3$  feet). If the cable is too short, reflected impedance can cause loss of communication data packets and spurious node errors.

At a speed of 1.5 Mbps, the maximum cable length is 200 meters; for speeds of 3, 6, and 12 Mbps, the maximum cable length is 100 meters. If longer cable lengths are needed, repeaters can be incorporated into the system.

# PROFIBUS Status LEDs

This following figure and tables describe the functionality of the PROFIBUS Status LEDs on the SmartMotor.



## LED Status on Power-up:

- With no program the travel limit inputs are low:  
LED 0 will be solid red indicating the motor is in a fault state due to travel limit fault.  
LED 1 will be off
- With no program and the travel limits are high:  
LED 0 will be solid red for 500 milliseconds and then begin flashing green.  
LED 1 will be off
- With a program that only disables travel limits and nothing else:  
LED 0 will be solid red for 500 milliseconds and then begin flashing green.  
LED 1 will be off

# PROFIBUS Configuration

The following sections describe how to configure your SmartMotor to communicate over PROFIBUS.

<b>Configure Motor with PC .....</b>	<b>24</b>
User Program Requirements .....	24
Required Nonvolatile EEPROM Values .....	24
Reserved Motor Variables .....	25
<b>Configure PLC with PC .....</b>	<b>25</b>
<b>Configure SmartMotor to PROFIBUS .....</b>	<b>25</b>
PLC Sends Commands to Motor .....	25
Network Data Format Example .....	26
PLC Memory .....	27
Sequence to Set Report Data to Motor Clock .....	28
<b>PROFIBUS Communication Example .....</b>	<b>29</b>

## Configure Motor with PC

Use the following procedure to configure the SmartMotor for communication with the PC. Refer to the figures in PROFIBUS Communication Example on page 29.

1. Connect the SmartMotor to the power supply.
2. If the motor is already configured, you may skip the balance of this procedure.
3. Connect the motor to the PC.
4. Launch the SmartMotor™ Interface (SMI) software, version 2.4.3.6 or later.

## User Program Requirements

No user program is specifically required by the Class 5 PROFIBUS SmartMotor.

## Required Nonvolatile EEPROM Values

The nonvolatile settings can be entered using the SMI software's Terminal window. For details on using the Terminal window, see the SMI software online help.

After the configuration settings have been entered, cycle the SmartMotor's power for the new configuration to take effect.

Use the following terminal commands to set the values:

- Set the PROFIBUS node ID to 3:  
`CADDR=3`
- Set the polling rate as fast as possible. In this command, the first number sets the poll rate, the second number is the number of microseconds to wait between polling loops.  
`CANCTL(8,0)`
- Set the action to take on network lost:  
`CANCTL(9,0)`
- Set the program label to jump to on network lost (if selected):  
`CANCTL(6,0)`

For the previous settings:

- `CADDR=` is mandatory, and the rest are optional. The defaults for the commands shown here are from the EEPROM; therefore, no assumptions should be made.
- `CANCTL(8,0)` by default EEPROM values would provide the fastest possible polling rate.
- `CANCTL(9,0)` will take no action on network lost
- `CANCTL(6,0)` depends on the user's program — only relevant when the "network lost" option is set to "GOSUB or GOTO a program label"



## Reserved Motor Variables

The Class 5 PROFIBUS motor does not need to reserve any user variables as the Class 4 motor did. The variables yyy and zzz are not affected unless they are deliberately accessed by the user. EPTR may be used by the user and is not modified by PROFIBUS activity as the Class 4 was. VST and VLD commands are also independent on PROFIBUS.

## Configure PLC with PC

Use the following procedure to configure the PLC for communication with the PC. Refer to the figures in PROFIBUS Communication Example on page 29.

**NOTE:** You may skip this section if the PLC is already configured.

1. Using the PLC configuration software running in a PC, load the SmartMotor's GSD file, set it up as a PROFIBUS node, from the catalog, and define the node number of the motor. For more details on the GSD file, see Software on page 10.
2. Set up the PLC memory that is the three words (six bytes) PROFIBUS output to the SmartMotor and the seven words (fourteen bytes) input from the SmartMotor.

## Configure SmartMotor to PROFIBUS



**CAUTION:** PROFIBUS *requires* termination and bias resistors at each end of the bus. If the PROFIBUS connectors have terminator switches, make sure the terminator switches at both ends of the PROFIBUS bus are ON, and all other terminator switches are OFF. For details, see Cables and Diagram on page 19.

---

Use the following procedure to configure the SmartMotor to PROFIBUS. Refer to the PROFIBUS Status LEDs on page 22.

1. Plug the PROFIBUS connector into the motor.
2. Power up or power cycle the motor. For 2 seconds, the PROFIBUS LEDs on the motor in the proximity of the PROFIBUS connector will have meaningless states.
3. If the PLC is running, within a few seconds the PROFIBUS connection status LED on the motor will turn GREEN, indicating the PROFIBUS Master has established a connection with the slave motor.

## PLC Sends Commands to Motor

Program the PLC or modify by hand the PLC memory areas, as described below, to send the desired commands over PROFIBUS and communicate with the motor.

The following are sequences of commands sent, which show all the intermediary PROFIBUS packet output data states.

**NOTE:** Bold characters indicate changes in the PLC memory output buffer and input buffer values.

## Network Data Format Example

Each byte below is represented as two hexadecimal characters. For example, 7A represents hex 7A or decimal 122.

COMMAND FROM I/O CONTROLLER						RESPONSE FROM SMART MOTOR			
Cmd Code	Resp Code	Data		Cmd Code Ack	Resp Code Ack	Resp Data	Status Word	Measured Position	Pos Error
00	7A	0000 0000	.....	00	00	0000 0000	0680	0000 0000	0000

The following are the SmartMotor's Status Word response bit definitions (the response shown above is 0680).

### Status Bits for Class 5 Mode (Default)

Bit	Description
0	Busy Trajectory
1	Historical + limit (hardware and software limit)
2	Historical - limit (hardware and software limit)
3	Index report available for the rising edge of internal encoder
4	Position wraparound occurred
5	Position error fault
6	Temperature limit fault
7	Drive off
8	Index input active
9	+ limit active (hardware and software limit)
10	- limit active (hardware and software limit)
11	Communication error of any type
12	User's status bit defined by CANCTL(12,x), see Nonvolatile Data on page 43
13	Command error (includes math and array errors)
14	Peak overcurrent occurred
15	Drive ready

## Status Bits for Class 4 Emulation Mode

**NOTE:** CANCTL(11,1) enables Class 4 emulation mode; CANCTL(11,0) disables Class 4 emulation mode.

Bit	Description
0	Busy Trajectory
1	Historical + limit (hardware and software limit)
2	Historical - limit (hardware and software limit)
3	Index report available for the rising edge of internal encoder
4	Position wraparound occurred
5	Position error fault
6	Temperature limit fault
7	Drive off
8	Index input active
9	+ limit active (hardware and software limit)
10	- limit active (hardware and software limit)
11	Math overflow
12	Array index error
13	Syntax error
14	Peak overcurrent occurred
15	Program checksum error

## PLC Memory

Each byte below is represented as two hexadecimal characters. For example, 0680 represents hex 680 or decimal 134.

### Output to slave motor:

3 two-byte words out

0000 0000 0000

### Input from slave motor:

7 two-byte words in

0000 0000 0000 0086 0000 0000 0000

A status word of 0x0680 (which breaks down to the bits 0000 0110 1000 0000) indicates the servo is off, the left and right limits have been activated, and the drive is not ready.

## Sequence to Set Report Data to Motor Clock

Command Code	Response Code	Data	Motor Command
	0x7A		RCLK

Insert response code 0x**7A** in the output buffer, which is being transmitted continuously (i.e., cyclically) by the master to the slave motor. See Command Packet Codes to Motor Commands on page 52 to find response code RCLK and its value, hex 7A.

00**7A** 0000 0000                      0000 0000 0000 0680 0000 0000 0000

Wait for response code acknowledge in the input buffer, which is being received continuously (i.e., cyclically) by the master as a response from the slave motor. The clock data begins being cyclic updates.

007A 0000 0000                      00**7A** 0000 03A1 0680 0000 0000 0000

As time goes on, the clock data is updated.

007A 0000 0000                      007A **0001 B01A** 0680 0000 0000 0000


## PROFIBUS Communication Example

The example illustrates communication over PROFIBUS by sending commands from a PLC over PROFIBUS to cause the motor to continually report its changing clock value to the PLC. The value displayed by the PLC registers containing the PROFIBUS data received from the motor changes as the updated clock value is received from the motor.

**NOTE:** Your motor type may vary from the motor pictured below.


The create a PROFIBUS connection to the SmartMotor:

1. Install the SMI software. For more details, see the *Moog Animatics SmartMotor™ User's Guide*.
2. Refer to the following figure. Configure the motor through its serial port using a PC that is running the SMI software to:
  - a. Set PROFIBUS node number in motor non-volatile storage.




*Configuring the SmartMotor*

3. Refer to the following figure. Configure your PLC through its serial port using a PC that is running your PLC configuration software to:
  - a. Load the motor's PROFIBUS GSD file
  - b. Assign and display the PLC registers associated with the motor's PROFIBUS input and output data



*Configuring the PLC*

4. Refer to the following figure. Connect a PROFIBUS cable to the PLC and to the SmartMotor.



*PROFIBUS Communication between PC, PLC and SmartMotor*

5. Power cycle the motor to initialize the motor with the configured values.
6. Using a PC that is running the PLC software and the PLC online (see the previous figure):
  - a. Enter the PROFIBUS motor command to report motor clock in the PLC PROFIBUS data registers.
  - b. Watch the clock value being updated in the PLC PROFIBUS input registers.

For examples of sending command sequences and communication handshaking, refer to Sample Command Sequences on page 33.





# Sample Command Sequences

This chapter contains sample PROFIBUS command sequences.

<b>Overview .....</b>	<b>34</b>
Command and Response Codes .....	34
Handshaking of Messages .....	34
Disabling Limits from Preventing Motion .....	34
Turning the Motor Shaft .....	34
<b>Disable Limits and Clear Fault Status .....</b>	<b>35</b>
Commands .....	35
PLC Memory .....	35
Disable positive limit, command EIGN(2) .....	35
Disable negative limit, command EIGN(3) .....	36
Clear fault status, command ZS .....	36
<b>Initiate Mode Torque .....</b>	<b>37</b>
Commands .....	37
PLC Memory .....	37
Set torque value, specify the response data .....	37
Initiate torque mode, command MT .....	37
<b>Initiate Relative Position Move .....</b>	<b>39</b>
Commands .....	39
PLC Memory .....	39
Set acceleration value, command ADT=255 .....	39
Set maximum velocity value, command VT=100000 .....	39
Make a relative position move .....	40

## Overview

These sequences illustrate:

- Disabling limits from preventing motion
- Turning the shaft in torque mode
- Moving a relative distance
- Command and response codes
- Handshaking of messages

## Command and Response Codes

The command and response codes are described in Command Packet Codes to Motor Commands on page 52. The symbolic command and response codes are listed, along with their values and the related SmartMotor™ command. See Output and Input Packets on page 45 for further explanation of how to use the command and response codes.

## Handshaking of Messages

Handshaking of output message changes is included in the protocol to ensure coherence in the packet. See Output and Input Packets on page 45 for an explanation of handshaking.

## Disabling Limits from Preventing Motion

At power up, if limit switches are not connected to the motor, the electrical state of the limit pins will default to indicate that the motor is at the limits. This will prevent motion unless the limits are disabled and any limit faults are cleared.

These commands may be included in the user program that is downloaded to the motor and runs at power up. If the user program does *not* include these commands or the limits are not held inactive at power-up, before attempting to turn the motor shaft, you must perform the command sequence described in Disable Limits and Clear Fault Status on page 35.

## Turning the Motor Shaft

After disabling the limits and clearing any faults, the shaft may be turned using the following command sequences:

- Initiate Mode Torque on page 37
- Initiate Relative Position Move on page 39

These sequences are described in following sections.

# Disable Limits and Clear Fault Status

## Commands

Command Code	Response Code	Data	Resulting SmartMotor Command
0x01		0x30	EIGN(2)
0x01		0x33	EIGN(3)
0x01		0x44	ZS

## PLC Memory

### Output to slave motor:

3 words out

0000 0000 0000

### Input from slave motor:

7 words in

0000 0000 0000 0680 0000 0000 0000

Cmd Code	Resp Code	Data		Cmd Code Ack	Resp Code Ack	Resp Data	Status Word	Measured Position	Pos Error
00	7A	0000 0000	.....	00	00	0000 0000	0680	0000 0000	0000

## Disable positive limit, command EIGN(2)

Insert command EIGN(2) data = 0x30 in the output buffer, which is being transmitted continuously (i.e., cyclically) by the master to the slave motor.

0000 0000 00**30**

0000 0000 0000 0680 0000 0000 0000

Set command code 0x01 in the output buffer.

**01**00 0000 0030

0000 0000 0000 0680 0000 0000 0000

Wait for a command code acknowledge in the input buffer, which is being received continuously (i.e., cyclically) by the master as a response from the slave motor.

0100 0000 0030

**01**00 0000 0000 0480 0000 0000 0000

The command code acknowledges the motor has received the command.

Clear the command code in the output buffer (handshake) to prepare for the next command.

**00**00 0000 0030

0100 0000 0000 0480 0000 0000 0000

Wait for acknowledgment of the cleared command code.

0000 0000 0030

**00**00 0000 0000 0480 0000 0000 0000

0000 0000 00**33**

0000 0000 0000 0480 0000 0000 0000

Set command code 0x01 in the output buffer.

**01**00 0000 0033                      0000 0000 0000 0480 0000 0000 0000

Wait for command code acknowledge in the input buffer, which is being received continuously (i.e., cyclically) by the master as a response from the slave motor.

0100 0000 0033                      **0100 0000 0000 0080 0000 0000 0000**

The command code acknowledges the motor has received the command.

Clear the command code in the output buffer (handshake) to prepare for the next command:

**0000** 0000 0033                      0100 0000 0000 0080 0000 0000 0000

Wait for acknowledgment of the cleared command code.

0000 0000 0033                      **00**00 0000 0000 0080 0000 0000 0000

## Clear fault status, command ZS

Insert command ZS data = 0x44 in output buffer, which is being transmitted continuously (i.e., cyclically) by the master to the slave motor.

0000 0000 00**44** 0000 0000 0000 **0086** 0000 0000 0000

Set command code 0x01 in the output buffer.

**01**00 0000 0044                      0000 0000 0000 0086 0000 0000 0000

Wait for command code acknowledge in the input buffer, which is being received continuously (i.e., cyclically) by the master as a response from the slave motor. Fault status is reported cleared to 0x**0080**.

0100 0000 0044                      **01**00 0000 0000 **0080** 0000 0000 0000

The command code acknowledges the motor has received the command.

Clear command code in output buffer (handshake) to prepare for the next command.

**00**00 0000 0044                      0100 0000 0000 0080 0000 0000 0000

Wait for acknowledgment of the cleared command code.

0000 0000 0044                      **00**00 0000 0000 0080 0000 0000 0000

# Initiate Mode Torque

## Commands

Command Code	Response Code	Data	Resulting SmartMotor Command
0x94	0xA2	3072 (0x0c00)	T=3072 RVA (polled motor response)
0x01	0xA2	0x21	MT RVA (polled motor response)
0x01		0x0C	G (begin motion)

## PLC Memory

### Output to slave motor:

3 words out

0000 0000 0000

### Input from slave motor:

7 words in

0000 0000 0000 0080 0000 0000 0000

## Set torque value, specify the response data

This will command T=3072 and specify the response data to be the current velocity.

Begin to set torque T=3072 by putting **x 00 00 0C 00** in output data.

0000 **0000 0C00**

0000 0000 0000 0080 0000 0000 0000

Insert command code 0x**94** and response code 0xA**2**.

**94A2** 0000 0C00

0000 0000 0000 0080 0000 0000 0000

Wait for acknowledge in input buffer:

94A2 0000 0C00

**94A2** 0000 0000 0080 0000 0000 0000

Now, T=3072 (0x0c00), and the response data value will be velocity. Clear the command code output buffer (handshake) to prepare for the next command.

**00A2** 0000 0C00

94A2 0000 0000 0080 0000 0000 0000

Wait for acknowledgment of command code clear in input buffer.

00A2 0000 0C00

**00A2** 0000 0000 0080 0000 0000 0000

## Initiate torque mode, command MT

Insert command 0x21 data to begin torque mode.

00A2 **0000 0021**

00A2 0000 0000 0080 0000 0000 0000

Insert command code 0x01.

**01A2** 0000 0021                      00A2 0000 0000 0080 0000 0000 0000

Wait for command code 1 acknowledgment.

01A2 0000 0021                      **01A2** 0000 0000 0080 0000 0000 0000

Insert command code 0x00.

**00A2** 0000 0021                      01A2 0000 0000 0080 0000 0000 0000

Wait for command code 0 acknowledgment.

00A2 0000 0021                      **00A2** 0000 0000 0080 0000 0000 0000

Insert command 0x0C data to initiate open-loop motion.

00A2 0000 **000C**                      00A2 0000 0000 0080 0000 0000 0000

Insert command code 0x01.

**01A2** 0000 000C                      00A2 0000 0000 0080 0000 0000 0000

When the command is received by the motor, the motor shaft will begin turning if it is not in a fault state.

Wait for command code acknowledgment in the input buffer.

01A2 0000 000C                      **01A2** 0000 0000 0080 0000 0000 0000

Velocity becomes nonzero, and it is reported as 0x**00 14 00 00** in this example. Status changes are reported as 0x**0009** in this example. Position becomes nonzero, and it is reported as 0x**00 00 00 A2** in this example.

01A2 0000 000C                      01A2 **0014 0000 0009 0000 00A2** 0000

Insert command code 0x00 to clear the command code output buffer (handshake) to prepare for the next command. The position is continually updated. Velocity is a filtered value measured in:

encoder counts per sample period x 65,536

**00A2** 0000 000C                      01A2 0014 0000 0009 **0000 02EE** 0000

Wait for the command code clear acknowledge in the input buffer.

00A2 0000 0000                      **00A2** 0014 0000 0009 **0000 05DC** 0000

Set data to 0.

0000 0000 0000                      00A2 0014 0000 0009 0000 05DC 0000

# Initiate Relative Position Move

## Commands

Command Code	Response Code	Data	Resulting SmartMotor Command
0x64		255 (0xff)	ADT=255
0xA3		100000	VT=100000
0x01		0x1D	Change to Mode Position (MP)
	0xA2		RVA (polled motor response)
0x03		10000	PRT=10000 G

## PLC Memory

### Output to slave motor:

3 words out

0000 0000 0000

### Input from slave motor:

7 words in

0000 0000 0000 0080 0000 0000 0000

## Set acceleration value, command ADT=255

Begin to set ADT=255 by putting x**00 00 00 FF** in output data.

0000 **0000 00FF**

0000 0000 0000 0080 0000 0000 0000

Insert command code 0x64 and response code 0xA2.

**64A2** 0000 00FF

0000 0000 0000 0080 0000 0000 0000

Wait for acknowledge in input buffer.

64A2 0000 00FF

**64A2** 0000 0000 0080 0000 0000 0000

Now, ADT=255, and the response data value will be velocity. Clear the command code output buffer (handshake) to prepare for the next command.

**00A2** 0000 00FF

64A2 0000 0000 0080 0000 0000 0000

Wait for acknowledge of command code clear in input buffer.

00A2 0000 00FF

**00A2** 0000 0000 0080 0000 0000 0000

## Set maximum velocity value, command VT=100000

Insert code commanded velocity of VT=100000 = 0x**0001 86A0**.

00A2 **0001 86A0**

00A2 0000 0000 0080 0000 0000 0000

**A3**A2 0001 86A0 00A2 0000 0000 0080 0000 0000 0000

Wait for command code acknowledge in the input buffer.

A3A2 0001 86A0                      **A3**A2 0000 0000 0080 0000 0000 0000

Insert command code 0x**00**.

**00**A2 0001 86A0                      A3A2 0000 0000 0080 0000 0000 0000

Wait for command code acknowledge in the input buffer.

00A2 0001 86A0                      **00**A2 0000 0000 0080 0000 0000 0000

Insert data 0x**0000 001D** for MP when command is 1.

[illegible]

Insert command code 0x**01**.

```
01A2 0001 86A0          00A2 0000 0000 0080 0000 0000 0000
```

Wait for command code acknowledge in the input buffer.

01A2 0001 86A0                      **01A2** 0000 0000 0080 0000 0000 0000

Insert command code 0x**00**.

00A2 0001 86A0 01A2 0000 0000 0080 0000 0000 0000

## Make a relative position move

Insert data for a relative move of 10,000 counts = 0x**0000 2710**.

00A2 **0000 2710**                      00A2 0000 0000 0080 0000 0000 0000

Insert command code value 0x03.

**03**A2 0000 2710 00A2 0000 0000 0080 0000 0000 0000

Wait for command code acknowledge in the input buffer.

**03A2** 0000 2710                      **03A2** 0000 0000 0080 0000 0000 0000

The motor performs its move. While the trajectory is in the slew phase, you will see something like:

03A2 0000 2710 03A2 0001 86AD 0009 0000 CA23 0011



which is the following input data:

command code acknowledge	03
response code acknowledge	A2
response data current	0001 86AD
velocity (100,000 in slew)	
status	0009
Bt = 1	
Bi = 1	
measured current position	0000 CA23
measured current position error	0011



# Nonvolatile Data

The motor stores some information about the PROFIBUS network in EEPROM, and it must be initialized with the data shown in the following table. This is accomplished through serial channel 0 using the CANCTL(function, value) and CADDR= commands. After a connection to the PROFIBUS Master had been established, it would be possible to modify these values through PROFIBUS. These commands are described in the PROFIBUS Packet Commands section of this manual. For details, see Output and Input Packets on page 45.

The Class 5 PROFIBUS interface is not a gateway expansion in the same way the Class 4 PROFIBUS expansion was. Therefore, these values are more integrated into the Class 5 motor with unique commands.

**NOTE:** Nonvolatile memory will be read at power-up or after the Z (reset) command has been executed.

Command	Description/ Parameter	Values
CADDR=	PROFIBUS node (MACID)	Typically 3 to 127; 63 is the factory default.
CANCTL(1,0)	Reset PROFIBUS	Resets the PROFIBUS hardware and protocol stack.
CANCTL(6, <value>)	NET_LOST_LABEL	Program label to jump to if the NET_LOST_LABEL option is chosen from the NET_LOST_ACTION function. This function has no effect if the NET_LOST_ACTION is anything other than NET_LOST_LABEL.
CANCTL(7,<value>)	Axis identifier (not MACID)	A 32-bit value settable and readable through PROFIBUS. Not required for normal operation and may be ignored.
CANCTL(8, <value>)	POLL_RATE	<p>Polling rate of the PROFIBUS service in microseconds. 0 is as fast as possible.</p> <p>Note that full microsecond resolution is not available, but the service time is typically under 1 millisecond. This setting allows for slowing down PROFIBUS service to allow more CPU time for user programs.</p>
CANCTL(9,<value>)	NET_LOST_ACTION	<p>Action to take if PROFIBUS network is lost.</p> <p>(Master is no longer communicating to slave; timeout of master occurs in the SmartMotor.)</p> <p>&lt;value&gt;:</p> <ul style="list-style-type: none"> <li>0 - IGNORE</li> <li>1 - Send command OFF to motor</li> <li>2 - Send command X to motor (soft stop)</li> <li>3 - Send command S to motor (immediate stop)</li> <li>4 - Send command GOSUB(x), where x is the value of NET_LOST_LABEL</li> <li>5 - Send command GOTO(x), where x is the value of NET_LOST_LABEL</li> </ul>
CANCTL(10,<value>)	SET_PA_FIELD	<p>Configure the PROFIBUS input packet to use an alternate data source for the "Measured position" field (words 4,5).</p> <p>&lt;value&gt;:</p> <ul style="list-style-type: none"> <li>0 - Report actual position in encoder counts (the power-up default value)</li> <li>1 - Report al[0] (big-endian format)</li> <li>2 - Report af[0] (IEEE-754, 32-bit, single-precision, big-endian format)</li> </ul>

Command	Description/ Parameter	Values
CANCTL(11,<value>)	Class 4 emulation	<p>Configure the motor to perform certain actions similar to Class 4. Value is reset to 0 (Class 5 mode) when motor is reset. This value is not stored in the EE.</p> <p>0 - Behave like a Class 5 (power-on default) 1 - Perform certain actions like Class 4:</p> <p>Status word contains math error instead of communication error and array error, these are cleared by ZS.</p> <p>Status word index capture bit resets on index read, index re-armed by the read.</p> <p>Status word checksum error instead of drive ready.</p> <p>CMD_Zd works through PROFIBUS to clear math overflow.</p> <p>CMD_Zu works through PROFIBUS to clear array error.</p>
CANCTL(12,<value>)	Control user status bit	<p>When in Class 5 mode (Class 4 emulation disabled), it is possible to use bit 12 in the PROFIBUS status word as a user-controlled bit. The user can choose what purpose this is used for.</p> <p>&lt;value&gt; :</p> <p>0- Clear bit 12 in the PROFIBUS status word 1- Set bit 12 in the PROFIBUS status word</p>

## Program Example

The following code example sets the nonvolatile station name.

```

a=<address>
IF CADDR!=a
  CADDR=a
  Z      'Reboot motor with new address
ENDIF

```

# Output and Input Packets

This section describes the PROFIBUS Output and Input packet format. It also provides notes for the Command (Output) packets and Response (Input) Packets.

<b>Output and Input Packet Format .....</b>	<b>46</b>
<b>Command (Output) Packet Notes .....</b>	<b>47</b>
<b>Response (Input) Packet Notes .....</b>	<b>48</b>

# Output and Input Packet Format

## Output Data Format (I/O Controller Command)

Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	0	Command Code							
	1	Response Code							
1	2	Command Data Value (32 bits), big-endian format							
	3								
2	4								
	5								

## Input Data Format (Motor response)

Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	0	Command Code Acknowledge							
	1	Response Code Acknowledge							
1	2	Response Data Value (32 bits), big-endian format							
	3								
2	4								
	5								
3	6	Status Word (16 bits), big-endian format							
	7								
4	8	Measured Position (32 bits), big-endian format NOTE: This field can be configured to report al[0] or af[0].							
	9								
5	10								
	11								
6	12	Position Error (16 bits), big-endian format							
	13								

**Command Code:** Indicates a command to be issued to the SmartMotor. Also, see Command Data Value.

**Response Code:** Indicates additional data to be included in the Response Data Value of the Input Data.

**Command Data Value:** Indicates the 32-bit value to be used in conjunction with the Command Code.

**Command Code Acknowledge:** Returned in the Input Data to indicate that a Command Code was processed.

**Response Code Acknowledge:** Returned in the Input Data to indicate that a Response Code was processed and that the current Response Data Value corresponds to that Response Code.

**Response Data Value:** 32-bit value returned in the Input Data in response to a Response Code.

**Status Word:** SmartMotor's current status word (16 bit).

**Measured Position:** SmartMotor's current measured position value (32-bit); result of RPA command.

**Position Error:** SmartMotor's current commanded trajectory position less the current measured position.

## Command (Output) Packet Notes

The following are notes regarding the Command (Output) Packets:

- A command is issued to the SmartMotor exactly one time after the Command Code or Command Data Value changes in the output data. To issue a command:
  - a. Set the Command Code to 0.
  - b. Wait for Command Code Acknowledge = 0.
  - c. Set the Command Data Value to the desired value.
  - d. Set the Command Code to the desired command.
  - e. Wait for Command Code Acknowledge = Command Code.
- For <value>, insert the Command Data Value.
- For the variables <a to zzz>:
  - <a to z> u8VarIndexSet (0-25)
  - <aa to zz> u8VarIndexSet (26-51)
  - <aaa to zzz> u8VarIndexSet (52-77)
- For <index>, insert the array index stored in u8ArrIndexSetActual.
- For <length>, insert the length stored in u8VarLenSet or u8ArrLenSet.
- Curly brackets {} indicate binary data rather than ASCII characters.
- The Polling Rate (u32PollRate) is the minimum time (in microseconds) to wait between sending status requests, position requests, and requests associated with the Response Codes and commands. The microsecond scaling of this value is to support the higher-speed nature of the Class 5 PROFIBUS interface. It does not imply that there is a response time with a resolution of single microseconds. Setting this value to 0 polls the PROFIBUS interface as fast as possible, which is approximately 300-500 microseconds.
- The SmartMotor variable yyy is no longer used by the PROFIBUS module in the Class 5 motor, as compared to the Class 4 PROFIBUS interface. The Class 5 memory map also differs such that ab[200], aw[100] and al[50] do not share space with variable yyy. That means those array locations are also not affected by the PROFIBUS interface.
- The PROFIBUS interface does not interfere with the SmartMotor's EPTR command for access to EEPROM. Therefore, the user program may use the EPTR command at the same time.
- If an invalid value of the MACID (not 0-125) is found at startup, then the PROFIBUS Default Address of 126 will be used.

## Response (Input) Packet Notes

The following are notes regarding the Command (Output) Packets:

- The requests associated with any Response Codes other than 214-225 are issued to the SmartMotor continuously (or according to the polling rate if set). When the Response Code in the output data transitions to a value in the range of 214-225, the associated request will be issued to the SmartMotor exactly one time after transition to one of those values. To issue a request for data:
  - a. Set the Response Code to 0.
  - b. Wait for Response Code Acknowledge = 0.
  - c. Set the Response Code to the desired value.
  - d. Wait for Response Code Acknowledge = Response Code read data from Response Data Value.
  - e. Repeat as desired if not Response Codes 214-225.
- The Polling Rate (u32PollRate) is the minimum time (in microseconds) to wait between sending status requests, position requests, and requests associated with the Response Codes and commands. The microsecond scaling of this value supports the higher-speed nature of the Class 5 PROFIBUS interface. It does not imply that there is a response time with a resolution of single microseconds. When this value is set to 0, it polls the PROFIBUS interface as fast as possible, which is approximately 300-500 microseconds.
- For <value>, insert the Response Data Value.
- For the variables <a to zzz>:
  - <a to z> u8VarIndexGet (0-25)
  - <aa to zz> u8VarIndexGet (26-51)
  - <aaa to zzz> u8VarIndexGet (52-77)
- For <index>, insert the array index stored in u8ArrIndexGetActual.
- For <length>, insert the length stored in u8VarLenGet or u8ArrIndexGet.
- Curly brackets {} indicate binary data rather than ASCII characters.
- The Response Data Value for a GET\_MODE (SmartMotor RMODE) command will contain the integer code returned by the SmartMotor, which may be unexpected by users familiar with the RMODE command in older Moog Animatics products. For details on the RMODE command, see the *Moog Animatics SmartMotor™ Command Reference Guide*.
- The SmartMotor variable yyy is not used by the PROFIBUS module. Therefore, the user program may use variable yyy. In the memory map, ab[200], aw[100] and al[50] do not share space with variable yyy. This means that those array locations are also not affected by the PROFIBUS interface. This functionality may be unexpected by users familiar with older Moog Animatics products.



- The PROFIBUS interface does not use the SmartMotor's EPTR command during initialization to read startup parameters from the SmartMotor. Therefore, the user program may use EPTR command at the same time. Also, the SmartMotor variable zzz is not used by the PROFIBUS interface, which may be unexpected by users familiar with older Moog Animatics products.
- If an invalid value of the MACID (not 0-125) is found at startup, then the PROFIBUS default address of 126 will be used.

# Alternate Communications Channel

In addition to communicating over PROFIBUS, commands in the SmartMotor™ programming language may be sent through an existing communications channel of the SmartMotor. For details, see the *Moog Animatics SmartMotor™ User's Guide*.

## Reserved Motor Variables

The PROFIBUS interface does not:

- Require the reservation of any user variables. Some older Moog Animatics products required the reservation of yyy and zzz. However, this is not the case in the PROFIBUS interface—these variables are freely available for the user.
- Require the reservation of any serial channels. Therefore, all other ports and associated channels are freely available to the user for the application.
- Interfere with the EPTR variable of the EEPROM command set. When PROFIBUS accesses the EEPROM, it is done through a private version of EPTR. Therefore, the user no longer has to monitor variable zzz for shared access. The user may access the EEPROM at any time.

**NOTE:** EEPROM reads may still cause a user command to wait until the EEPROM is available, but there is no user interaction required.

# Command and Response Codes

This section lists the PROFIBUS packet command and response codes and their corresponding SmartMotor commands.

**Command Packet Codes to Motor Commands .....52**

**Response Packet Codes to Motor Commands .....60**

## Command Packet Codes to Motor Commands

This section provides a reference table of PROFIBUS command packet codes and corresponding SmartMotor commands.

Certain commands can have different meanings based on the SmartMotor style. For example, RBa will have the meaning associated with the style of the motor.

Variables beginning with u8, u16 or u32 are internal to the motor's PROFIBUS module.

For the variables:

- <a to z> use values (0 to 25)
- <aa to zz> use values (26 to 51)
- <aaa to zzz> use values (52 to 77)

Command Code	Command Data Value	Note	Command Description	Smart Motor Command(s)	Smart Motor Response
<i>decimal, hex</i>	<i>decimal, hex</i>				
0		NULL	No command		
1, x01	0, x00		Engage brake	BRKENG	
1, x01	1, x01		Use only internal brake; disable external brake	EOBK(-1)	
1, x01	2, x02		Direct brake to output number 6	EOBK(6)	
1, x01	3, x03		Direct brake to output number 2	EOBK(2)	
1, x01	4, x04		Release brake	BRKRLS	
1, x01	5, x05		Brake while servo inactive	BRKSRV	
1, x01	6, x06		Brake while trajectory inactive	BRKTRJ	
1, x01	7, x07	Reserved			
1, x01	8, x08		Select internal encoder for servo	ENC0	
1, x01	9, x09		Select external encoder for servo	ENC1	
1, x01	10, x0A		End user program	END	
1, x01	11, x0B		Transfer buffered PID tuning to live values	F	
1, x01	12, x0C		Start motion (GO)	G	
1, x01	13, x0D	Obsolete	Use KG=0	KG0FF	
1, x01	14, x0E	Obsolete	Use KG=<value>, command 131	KGON	
1, x01	15-18, x80F-x12	Obsolete			
1, x01	19, x13		Enable cam mode; not implemented	MC	
1, x01	20-22, x14-x16	Obsolete			
1, x01	23, x17		Enable contouring mode; not implemented	MD	
1, x01	24, x18		Set mode follow and zero out	MF0	
1, x01	25-27, x19-x1B	Obsolete			
1, x01	28, x1C		Initiate mode follow quadrature	MFR	
1, x01	29, x1D		Enable position mode	MP	
1, x01	30, x1E	Obsolete			
1, x01	31, x1F		Configure step and direction, and zero out	MS0	
1, x01	32, x20		Initiate mode step ratio calculation	MSR	

Command Code	Command Data Value	Note	Command Description	Smart Motor Command(s)	Smart Motor Response
<i>decimal, hex</i>	<i>decimal, hex</i>				
1, x01	33, x21		Enable torque mode	MT	
1, x01	34, x22		Immediately engage MTB brake	MTB	
1, x01	35, x23		Enable velocity mode	MV	
1, x01	36, x24		Stop servoing the motor	OFF	
1, x01	37, x25		Divide PID sample rate by 1	PID1	
1, x01	38, x26		Divide PID sample rate by 2, default	PID2	
1, x01	39, x27		Divide PID sample rate by 4	PID4	
1, x01	40, x28		Divide PID sample rate by 8	PID8	
1, x01	41, x29		Execute stored program	RUN	
1, x01	42, x2A		End program if RUN has not been commanded yet (since power up)	RUN?	
1, x01	43, x2B		Abruptly stop move in progress	S	
1, x01	44, x2C		Make I/O 0 an input; if a brake redirect, this is ignored	EIGN(0)	
1, x01	45, x2D	Obsolete	Use CMD_OUT(x)		
1, x01	46, x2E		Make I/O 1 an input; if a brake redirect, this is ignored	EIGN(1)	
1, x01	47, x2F	Obsolete	Use CMD_OUT(x)		
1, x01	48, x30		Make I/O 2 an input; if a brake redirect, this is ignored; disable right-limit function	EIGN(2)	
1, x01	49, x31	Obsolete	Use CMD_OUT(x)		
1, x01	50, x32		Set I/O C to be a right-limit input	EILP	
1, x01	51, x33		Make I/O 3 an input; if a brake redirect, this is ignored; disable left-limit function	EIGN(3)	
1, x01	52, x34	Obsolete	Use CMD_OUT(x)		
1, x01	53, x35		Set I/O 3 to be a left-limit input	EILN	
1, x01	54, x36		Slow motor motion to stop	X	
1, x01	55, x37		Total system reset	Z	
1, x01	56, x38		Reset overcurrent error bit	Za	
1, x01	57, x39		Reset serial data parity violation latch bit, i.e., clears the parity error bits in RCHN(0) and RCHN(1)		
1, x01	58, x3A		Reset communications buffer overflow latch bit, i.e., clears the overflow error bits in RCHN(0) and RCHN(1)		
1, x01	59, x3B		Available in Class 4 emulation mode only to reset math error		
1, x01	60, x3C		Reset position error fault	Ze	
1, x01	61, x3D		Reset serial communication framing error latch bit, i.e., clears the framing error bits in RCHN(0) and RCHN(1)		
1, x01	62, x3E		Reset over-temperature fault; requires temperature to fall 5 degrees below limit	Zh	
1, x01	63, x3F		Reset historical left-limit latch bit	Zl	
1, x01	64, x40		Reset historical right-limit latch bit	Zr	
1, x01	65, x41		Reset command scan error latch bit	Zs	

<b>Command Code</b>	<b>Command Data Value</b>	<b>Note</b>	<b>Command Description</b>	<b>Smart Motor Command(s)</b>	<b>Smart Motor Response</b>
<i>decimal, hex</i>	<i>decimal, hex</i>				
1, x01	66, x42		Available in Class 4 emulation mode only to reset array index error		
1, x01	67, x43		Reset encoder wraparound event latch bit	Zw	
1, x01	68, x44		Reset system latches to power-up state	ZS	
1, x01	69, x45		Disable software limits	SLD	
1, x01	70, x46		Enable software limits	SLE	
1, x01	71, x47		Make I/O 6 an input; if a brake redirect, this is ignored; disable GO synchronization function	EIGN(6)	
1, x01	72, x48		Enable GO synchronization function	EISM(6)	
1, x01	73, x49		Make I/O 4 an input. If a brake redirect, this is ignored	EIGN(4)	
1, x01	74, x4A		Make I/O 5 an input. If a brake redirect, this is ignored	EIGN(5)	
1, x01	75, x4B		Arm index capture from internal encoder, rising edge	Ai(0)	
1, x01	76, x4C		Arm index capture from internal encoder, falling edge	Aj(0)	
1, x01	77, x4D		Arm index capture from internal encoder, rising then falling edge	Aij(0)	
1, x01	78, x4E		Arm index capture from internal encoder, falling then rising edge	Aji(0)	
1, x01	79, x4F		Arm index capture from external encoder, rising edge	Ai(1)	
1, x01	80, x50		Arm index capture from external encoder, falling edge	Aj(1)	
1, x01	81, x51		Arm index capture from internal encoder, rising then falling edge	Aij(1)	
1, x01	82, x52		Arm index capture from internal encoder, falling then rising edge	Aji(1)	
1, x01	83, x53		Immediately force trapezoidal commutation mode	MDT	
1, x01	84, x54		Request enhanced trapezoidal commutation mode; entered as soon as angle is satisfied	MDE	
1, x01	85, x55		Request sine commutation mode (voltage mode); entered as soon as angle is satisfied	MDS	
1, x01	86, x56	Reserved			
1, x01	87, x57		Turn on Trajectory Overshoot Braking (TOB) feature for trapezoidal mode	MDB	
1, x01	88+, x58+	Reserved			
2, x02	<value>	DO_MOVE_POS_ABS	Set absolute position and start motor	PT=<value> G	
3, x03	<value>	DO_MOVE_POS_REL	Set relative position and start motor	PRT=<value> G	
4, x04	<value>	DO_MOVE_VEL	Set velocity and start motor	VT=<value> G	
5, x05	<value>		Call a subroutine	GOSUB(<value>)	
6, x06	<value>		Branch program execution to a label	GOTO(<value>)	

Command Code	Command Data Value	Note	Command Description	Smart Motor Command(s)	Smart Motor Response
<i>decimal, hex</i>	<i>decimal, hex</i>				
7-89, x07-x59		Reserved			
90, x5A	<value>		Clear mask on user bits, word 0, status word 12	UR(W,0,<value>)	
91, x5B	<value>		Clear mask on user bits, word 1, status word 13	UR(W,1,<value>)	
92, x5C	<value>		Set mask on user bits, word 0, status word 12	US(W,0,<value>)	
93, x5D	<value>		Set mask on user bits, word 1, status word 13	US(W,1,<value>)	
94, x5E	<value>		Clear specific user bit 0-31	UR(<value>)	
95, x5F	<value>		Set specific user bit 0-31	US(<value>)	
96, x60	<value>		Set digital output 4 to 0 or 1	OUT(4)=<value>	
97, x61	<value>	Reserved			
98, x62	<value>		Set digital output 5 to 0 or 1.	OUT(5)=<value>	
99, x63	<value>	Reserved			
100, x64	<value>		Set acceleration	ADT=<value>	
101, x65	<value>		Set RS-232/RS-485 address	ADDR=<value>	
102, x66	<value>		Set PWM drive signal limit	AMPS=<value>	
103-123, x67-x7B		Reserved			
124, x7C	<value>		Set relative distance (position)	PRT=<value>	
125, x7D	<value>		Set allowable position error	EL=<value>	
126, x7E		Reserved			
127, x7F		Obsolete			
128, x80		Reserved			
129, x81	<value>		PID acceleration feed forward	KA=<value>	
130, x82	<value>		PID derivative compensation	KD=<value>	
131, x83	<value>		PID gravity compensation; for limits, see the <i>Moog Animatics SmartMotor™ User's Guide</i>	KG=<value>	
132, x84	<value>		PID integral compensation	KI=<value>	
133, x85	<value>		PID integral limit	KL=<value>	
134, x86	<value>		PID proportional compensation	KP=<value>	
135, x87	<value>		PID derivative term sample rate	KS=<value>	
136, x88	<value>		PID velocity feed forward	KV=<value>	
137, x89	<value>		Mode follow with ratio divisor	MFDIV=<value>	
138, x8A	<value>		Mode follow with ratio multiplier	MFMUL=<value>	
139, x8B	<value>		Set origin	O=<value>	
140, x8C	<value>		Shift origin	OSH(<value>)	
141, x8D		Reserved			
142, x8E	<value>		Set absolute position target	PT=<value>	
143-144, x8F-x90		Reserved			
145, x91	<value>		Set RS-232/RS-485 address	SADDR<value>	
146-147, x92-x93		Reserved			
148, x94	<value>		Assign torque value in torque mode	T=<value>	

Command Code	Command Data Value	Note	Command Description	Smart Motor Command(s)	Smart Motor Response
<i>decimal, hex</i>	<i>decimal, hex</i>				
149, x95		Reserved			
150, x96	<value>		Set maximum allowable temperature (high limit)	TH= <value>	
151, x97		Reserved			
152, x98	<value>		Set I/O A output	OUT(0)= <value>	
153, x99		Reserved			
154, x9A	<value>		Set I/O B output	OUT(1)= <value>	
155, x9B		Reserved			
156, x9C	<value>		Set I/O C output	OUT(2)= <value>	
157, x9D		Reserved			
158, x9E	<value>		Set I/O D output	OUT(3)= <value>	
159, x9F		Reserved			
160, xA0	<value>		Set I/O G output	OUT(6)= <value>	
161-162, xA1-xA2		Reserved			
163, xA3	<value>		Set velocity target	VT= <value>	
164, xA4		Reserved			
165, xA5	<value>		Set value of negative software limit	SLN= <value>	
166, xA6	<value>		Set value of positive software limit	SLP= <value>	
167-169, xA7-xA9		Reserved			
170, xAA	<value>		Clear status word 0; bit indicated by value	Z(0,<value>)	
171, xAB	<value>		Clear status word 1; bit indicated by value	Z(1,<value>)	
172, xAC	<value>		Clear status word 2; bit indicated by value	Z(2,<value>)	
173, xAD	<value>		Clear status word 3; bit indicated by value	Z(3,<value>)	
174, xAE	<value>		Clear status word 4; bit indicated by value	Z(4,<value>)	
175, xAF	<value>		Clear status word 5; bit indicated by value	Z(5,<value>)	
176, xB0	<value>		Clear status word 6; bit indicated by value	Z(6,<value>)	
177-199, xB1-xC7		Reserved			
200, xC8	<a-zzz> 0-77	SET_VAR_INDEX_SET	u8VarIndexSet = <value> u8VarIndexSetActual = <value>		
201, xC9		Reserved			
202, xCA	<value> 0-78	SET_VAR_LEN_SET	u8VarLenSet = <value>		
203, xCB	<value> 0-203 ab[] 0-101 aw[] 0-50 al[]	SET_ARRAY_INDEX_SET	u8ArrIndexSet = <value> u8ArrIndexSetActual = <value>		
204, xCC		Reserved			
205, xCD	<value> 0-204 ab[] 0-102 aw[] 0-51 al[]	SET_ARR_LEN_SET	u8ArrLenSet = <value>		



Command Code	Command Data Value	Note	Command Description	Smart Motor Command(s)	Smart Motor Response
<i>decimal, hex</i>	<i>decimal, hex</i>				
206, xCE	<value> 0=NO, 1=YES	SET_AUTO_INC_SET	u8AutoIncSet = <value>		
207, xCF	<a-zzz> 0-77	SET_VAR_INDEX_GET	u8VarIndexGet = <value> u8VarIndexGetActual = <value>		
208, xD0		Reserved			
209, xD1	<value> 0-78	SET_VAR_LEN_GET	u8VarLenGet = <value>		
210, xD2	<value> 0-203 ab[] 0-101 aw[] 0-50 al[]	SET_ARRAY_INDEX_GET	u8ArrIndexGet = <value> u8ArrIndexGetActual = <value>		
211, xD3		Reserved			
212, xD4	<value> 0-204 ab[] 0-102 aw[] 0-51 al[]	SET_ARR_LEN_GET	u8ArrLenGet = <value>		
213, xD5	<value> 0=NO, 1=YES	SET_AUTO_INC_GET	u8AutoIncGet = <value>		
214, xD6	<value>	SET_VAR	Set variable <a to zzzz> = 'a'+u8VarIndexSetActual; if (u8AutoIncSet) then u8VarIndexSetActual += 1	<a to zzz> = <value>	
215, xD7	<value>	SET_ARRAY_BYTE	Set byte array variable <index>=u8ArrIndexSetActual; if (u8AutoIncSet) then u8ArrIndexSetActual += 1	ab[<index>]= <value>	
216, xD8	<value>	SET_ARRAY_WORD	Set word array variable <index>=u8ArrIndexSetActual; if (u8AutoIncSet) then u8ArrIndexSetActual += 1	aw[<index>]= <value>	
217, xD9	<value>	SET_ARRAY_LONG	Set long array variable <index>=u8ArrIndexSetActual; if (u8AutoIncSet) then u8ArrIndexSetActual += 1	al[<index>]= <value>	
218, xDA	<value>	SET_NVOL_BYTE	Store byte to EEPROM u32EpPtrActual += 1	VST(<value byte>,1)	
219, xDB	<value>	SET_NVOL_WORD	Store word to EEPROM u32EpPtrActual += 2	VST(<value word16>,1)	
220, xDC	<value>	SET_NVOL_LONG	Store long to EEPROM u32EpPtrActual += 4	VST(<value long>,1)	
221, xDD	<value>	SET_NVOL_VAR	Set variable and store to EEPROM <a to z>='a'+u8VarIndexSetActual u32EpPtrActual += 4; if (u8AutoIncSet) then u8VarIndexSetActual += 1	<a to z> = <value> VST(<a to z>,1)	
222, xDE		STORE_NVOL_VARS	Store variables to EEPROM <a to z>='a'+u8VarIndexSetActual <length>=u8VarLenSet u32EpPtrActual += (<length>*4); if (u8AutoIncSet) then u8VarIndexSetActual += <length>	VST(<a to z>, <length>)	

Command Code	Command Data Value	Note	Command Description	Smart Motor Command(s)	Smart Motor Response
<i>decimal, hex</i>	<i>decimal, hex</i>				
223, xDF		STORE_NVOL_ARRAY_BYTE	Store byte array variables to EEPROM <index>=u8ArrIndexSetActual <length>=u8ArrLenSet u32EpPtrActual += (<length>*1); if (u8AutoIncSet) then u8ArrIndexSetActual += <length>	VST(ab[<index>], <length>)	
224, xE0		STORE_NVOL_ARRAY_WORD	Store word array variables to EEPROM <index>=u8ArrIndexSetActual <length>=u8ArrLenSet u32EpPtrActual += (<length>*2); if (u8AutoIncSet) then u8ArrIndexSetActual += <length>	VST(aw [<index>], <length>)	
225, xE1		STORE_NVOL_ARRAY_LONG	Store long array variables to EEPROM <index>=u8ArrIndexSetActual <length>=u8ArrLenSet u32EpPtrActual += (<length>*4); if (u8AutoIncSet) then u8ArrIndexSetActual += <length>	VST(al[<index>], <length>)	
226, xE2	<value>		Set the EEPROM address u32EpPtrSet=<value> u32EpPtrActual=<value> (doesn't affect EPTR)		
227, xE3		Reserved			
228, xE4	<value> 0-999	SET_NET_LOST_LABEL	Set GOTO/GOSUB number for net lost action  u16NetLostLabel=<value> (initialized to the value of u16NetLostLabelDefault during power-up)		
229, xE5	<value>	SET_NET_LOST_ACTION	Set PROFIBUS network lost action  u8NetLostAction=<value> (initialized to the value of u8NetLostActionDefault during power-up)	Upon loss of communication with PROFIBUS host, command is based on <value>:  0=IGNORE (No Command), 1=OFF (Motor Off), 2=X (Soft Stop), 3=S (Immediate Stop), 4=GOSUB, 5=GOTO	
230, xE6	<value> 0 to 2047907 (approx. 2 seconds)	SET_POLL_RATE	Set rate (in us) at which the SmartMotor is polled by PROFIBUS u32PollRate=<value> (initialized to the value read from SmartMotor EEPROM location 32012 during power up)		
231, xE7	<value> 0-999	SET_NET_LOST_LABEL_DEFAULT	Set GOTO/GOSUB number for net lost action  u16NetLostLabelDefault=<value> (saved in nonvolatile storage in the SmartMotor)		

Command Code	Command Data Value	Note	Command Description	Smart Motor Command(s)	Smart Motor Response
<i>decimal, hex</i>	<i>decimal, hex</i>				
232, xE8	<value>	SET_NET_LOST_ACTION_DEFAULT	Set PROFIBUS network lost action u8NetLostActionDefault= <value> (saved in nonvolatile storage in the SmartMotor)	Upon loss of communication with PROFIBUS host, command is based on <value> :  0=IGNORE (No Command), 1=OFF (Motor Off), 2=X (Soft Stop), 3=S (Immediate Stop), 4=GOSUB, 5=GOTO	
233, xE9	<value>	SET_NET_DEVICE_ID	u32NetDeviceId= <value> (saved in nonvolatile storage in the SmartMotor)	CADDR= <value>	
234-239, xEA-xEF		Reserved			
240, xF0	<value>	SET_PA_FIELD	Configure the PROFIBUS input packet to use an alternate data source for the 'Measured position' field (words 4,5)  <value> : 0 - report actual position in encoder counts (this is the power-up default value) 1 - report al[0] (big-endian format) 2 - report af[0] (IEEE-754 32-bit single precision, big-endian format)	CANCTL(10,x)	
241-253, xF1-xFD		Reserved			
254, xFE		CMD_RESTORE_DEFAULTS	Restores all nonvolatile settings to the following defaults: u16NetLostLabelDefault=3 u8NetLostAction=IGNORE u32NetDeviceId=0 u32PollRate=0		
255, xFF		ERROR	Returned if the command code could not be performed successfully		

## Response Packet Codes to Motor Commands

This section provides a reference table of PROFIBUS response packet codes and corresponding SmartMotor commands.

Certain commands can have different meanings based on the SmartMotor style. For example, RBa will have the meaning associated with the style of the motor.

Variables beginning with u8, u16 or u32 are internal to the motor's PROFIBUS module.

For the variables:

- <a to z> use values (0 to 25)
- <aa to zz> use values (26 to 51)
- <aaa to zzz> use values (52 to 77)

Response Code	Response Data Value	Note	Response Description	Smart Motor Command(s)	Smart Motor Response
<i>decimal, hex</i>					
0, x00	0	NULL	No command		
1-95,					
x01-x5f		Reserved			
96, x60	<value>		Report digital I/O number 4	RIN(4)	
97, x61	<value>		Report analog input number 4	RINA(A,4)	
98, x62	<value>		Report digital I/O number 5	RIN(5)	
99, x63	<value>		Report analog input number 5	RINA(A,5)	
100, x64	<value>		Report acceleration target	RAT	<value>
101, x65	<value>		Get SmartMotor address	RADDR	<value>
102, x66	<value>		Report assigned PWM limit	RAMPS	<value>
103, x67	<value>		Report overcurrent status	RBa	<value>
104, x68	<value>		Class 4 emulation mode math overflow		
105, x69	<value>	Obsolete			
106, x6A	<value>	Obsolete			
107, x6B	<value>		Report position error status	RBe	<value>
108, x6C	<value>	Obsolete			
109, x6D	<value>		Report overheat status	RBh	<value>
110, x6E	<value>		Report index status	RBi	<value>
111, x6F	<value>		Report program checksum error	RBk	<value>
112, x70	<value>		Report historical left limit status	RBl	<value>
113, x71	<value>		Report negative limit status	RBm	<value>
114, x72	<value>		Report motor off status	RBo	<value>
115, x73	<value>		Report positive limit status	RBp	<value>
116, x74	<value>		Report historical right limit status	RBr	<value>
117, x75	<value>		Report program scan status	RBs	<value>
118, x76	<value>		Report trajectory status	RBt	<value>
119, x77	<value>	Obsolete			
120, x78	<value>		Report wrapped encoder position	RBw	<value>
121, x79	<value>		Report hardware index input level	RBx	<value>
122, x7A	<value>		Report millisecond clock	RCLK	<value>
123, x7B	<value>		Report secondary counter	RCTR(1)	<value>

## Response Packet Codes to Motor Commands

Response Code	Response Data Value	Note	Response Description	Smart Motor Command(s)	Smart Motor Response
<i>decimal, hex</i>					
124, x7C	<value>		Report buffered move distance value	RPRC	<value>
125, x7D	<value>		Report buffered maximum position error	REL	<value>
126, x7E		Reserved			
127, x7F	<value>	Obsolete			
128, x80	<value>		Report index position captured from recent Ai(0) command - object 1, data value 75. When Class 4 emulation, this re-arms the capture.	RI(0)	<value>
129, x81	<value>		Report buffered acceleration feed forward coefficient	RKA	<value>
130, x82	<value>		Report buffered derivative coefficient	RKD	<value>
131, x83	<value>		Report buffered gravity coefficient	RKG	<value>
132, x84	<value>		Report buffered integral coefficient	RKI	<value>
133, x85	<value>		Report buffered integral limit	RKL	<value>
134, x86	<value>		Report buffered proportional coefficient	RKP	<value>
135, x87	<value>		Report buffered sampling interval	RKS	<value>
136, x88	<value>		Report buffered velocity feed forward coefficient	RKV	<value>
137, x89	<value>		Report follow mode divisor	RMFDIV	<value>
138, x8A	<value>		Report follow mode multiplier	RMFMUL	<value>
139, x8B		Reserved			
140, x8C	<value>		Report current mode of operation	RMODE	<value>
141, x8D	<value>		Report present position	RPA	<value>
142, x8E	<value>		Report buffered position setpoint	RPT	<value>
143, x8F	<value>		Report present position error	REA	<value>
144-147, x90-x93		Reserved			
148, x94	<value>		Report current requested torque	RT	<value>
149, x95	<value>		Report temperature	RTEMP	<value>
150, x96	<value>		Report temperature shutdown limit	RTH	<value>
151, x97	<value>		Report current algorithm THD time	RTHD	<value>
152, x98	0=Bit 0 Off 1=Bit 0 On		Report digital I/O number 0	RIN(0)	<value>
153, x99	<value>		Report analog input number 0	RINA(A,0)	<value>
154, x9A	0=Bit 1 Off 1=Bit 1 On		Report digital I/O number 1	RIN(1)	<value>
155, x9B	<value>		Report analog input number 1	RINA(A,1)	<value>
156, x9C	0=Bit 2 Off 1=Bit 2 On		Report digital I/O number 2	RIN(2)	<value>
157, x9D	<value>		Report analog input number 2	RINA(A,2)	<value>
158, x9E	0=Bit 3 Off 1=Bit 3 On		Report digital I/O number 3	RIN(3)	<value>
159, x9F	<value>		Report analog input number 3	RINA(A,3)	<value>

## Response Packet Codes to Motor Commands

Response Code	Response Data Value	Note	Response Description	Smart Motor Command(s)	Smart Motor Response
<i>decimal, hex</i>					
160, xA0	0=Bit 6 Off 1=Bit 6 On		Report digital I/O number 6	RIN(6)	<value>
161, xA1	<value>		Report analog input number 6	RINA(A,6)	<value>
162, xA2	<value>		Report velocity	RVA	<value>
163, xA3	<value>		Report buffered maximum velocity	RVT	<value>
164, xA4	<value>		Report legacy status word	(n/a)	<value>
165, xA5	<value>		value of negative software limit	RSLN	<value>
166, xA6	<value>		value of positive software limit	RSLP	<value>
167, xA7	<value>	Reserved			
168, xA8	<value>		I/O 0-6, 7-bit value, right justified	RIN(W,0)	<value>
169, xA9		Reserved			
170, xAA	<value>		Report status word 0	RW(0)	<value>
171, xAB	<value>		Report status word 1	RW(1)	<value>
172, xAC	<value>		Report status word 2	RW(2)	<value>
173, xAD	<value>		Report status word 3	RW(3)	<value>
174, xAE	<value>		Report status word 4	RW(4)	<value>
175, xAF	<value>		Report status word 5	RW(5)	<value>
176, xB0	<value>		Report status word 6	RW(6)	<value>
177, xB1	<value>		Report status word 7	RW(7)	<value>
178, xB2	<value>		Report status word 8	RW(8)	<value>
179-181, xB3-xB5	<value>	Reserved			
182, xB6	<value>		Report user bits 0-15 (status word 12)	RW(12)	
183, xB7	<value>		Report user bits 16-31 (status word 13)	RW(13)	
184-185, xB8-xB9	<value>	Reserved			
186, xBA	<value>		Report I/O 0-7 (status word 16)	RW(16)	
187-199, xBB-xC7		Reserved			
200, xC8	<value>	GET_VAR_INDEX_SET	<value>=u8VarIndexSet		
201, xC9	<value>	GET_VAR_INDEX_SET_ACTUAL	<value>=u8VarIndexSetActual		
202, xCA	<value>	GET_VAR_LEN_SET	<value>=u8VarLenSet		
203, xCB	<value>	GET_ARRAY_INDEX_SET	<value>=u8ArrIndexSet		
204, xCC	<value>	GET_ARRAY_INDEX_SET_ACTUAL	<value>=u8ArrIndexSetActual		
205, xCD	<value>	GET_ARR_LEN_SET	<value>=u8ArrLenSet		
206, xCE	<value>	GET_AUTO_INC_SET	<value>=u8AutoIncSet		
207, xCF	<value>	GET_VAR_INDEX_GET	<value>=u8VarIndexGet		

## Response Packet Codes to Motor Commands

Response Code	Response Data Value	Note	Response Description	Smart Motor Command(s)	Smart Motor Response
<i>decimal, hex</i>					
208, xD0	<value>	GET_VAR_INDEX_GET_ACTUAL	<value>=u8VarIndexGetActual		
209, xD1	<value>	GET_VAR_LEN_GET	<value>=u8VarLenGet		
210, xD2	<value>	GET_ARRAY_INDEX_GET	<value>=u8ArrIndexGet		
211, xD3	<value>	GET_ARRAY_INDEX_GET_ACTUAL	<value>=u8ArrIndexGetActual		
212, xD4	<value>	GET_ARR_LEN_GET	<value>=u8ArrLenGet		
213, xD5	<value>	GET_AUTO_INC_GET	<value>=u8AutoIncGet		
214, xD6	<value>	GET_VAR	Get variable <a to zzz>='a'+u8VarIndexGetActual; if (u8AutoIncGet) then u8VarIndexGetActual += 1	R<a to zzz> (Issued only one time)	<value>
215, xD7	<value>	GET_ARRAY_BYTE	Get byte array variable <index>=u8ArrIndexGetActual; if (u8AutoIncGet) then u8ArrIndexGetActual += 1	Rab[<index>] (Issued only one time)	<value>
216, xD8	<value>	GET_ARRAY_WORD	Get word array variable <index>=u8ArrIndexGetActual; if (u8AutoIncGet) then u8ArrIndexGetActual += 1	Raw[<index>] (Issued only one time)	<value>
217, xD9	<value>	GET_ARRAY_LONG	Get long array variable <index>=u8ArrIndexGetActual; if (u8AutoIncGet) then u8ArrIndexGetActual += 1	Ral[<index>] (Issued only one time)	<value>
218, xDA	<value>	GET_NVOL_BYTE	Get byte from EEPROM u32EptrActual += 1	VLD(<value>,1) (Issued only one time)	<value>
219, xDB	<value>	GET_NVOL_WORD	Get word from EEPROM u32EptrActual += 2	VLD(<value>,1) (Issued only one time)	<value>
220, xDC	<value>	GET_NVOL_LONG	Get long from EEPROM u32EptrActual += 4	VLD(<value>,1) (Issued only one time)	<value>
221, xDD	<value>	GET_NVOL_VAR	Get variable from EEPROM <a to zzz>='a'+u8VarIndexGetActual; u32EptrActual += 4 if (u8AutoIncGet) then u8VarIndexGetActual += 1	VLD(<a to zzz>,1) R<a to zzz> (Issued only one time)	<value>
222, xDE		LOAD_NVOL_VARS	Load variables from EEPROM <a to zzz>='a'+u8VarIndexGetActual <length>=u8VarLenGet u32EptrActual += (<length>*4); if (u8AutoIncGet) then u8VarIndexGetActual += <length>	VLD(<a to zzz>,<length>) (Issued only one time)	
223, xDF		LOAD_NVOL_ARRAY_BYTE	Load byte array variables from EEPROM <index>=u8ArrIndexGetActual <length>=u8ArrLenGet u32EptrActual += (<length>*1); if (u8AutoIncGet) then u8ArrIndexGetActual += <length>	VLD(ab[<index>],<length>) (Issued only one time)	

## Response Packet Codes to Motor Commands

Response Code	Response Data Value	Note	Response Description	Smart Motor Command(s)	Smart Motor Response
<i>decimal, hex</i>					
224, xE0		LOAD_NVOL_ARRAY_WORD	Load word array variables from EEPROM <index>=u8ArrIndexGetActual <length>=u8ArrLenGet u32EptrActual += (<length>*2); if (u8AutoIncGet) then u8ArrIndexGetActual += <length>	VLD(aw [<index>], <length>) (Issued only one time)	
225, xE1		LOAD_NVOL_ARRAY_LONG	Load long array variables from EEPROM <index>=u8ArrIndexGetActual <length>=u8ArrLenGet u32EptrActual += (<length>*4); if (u8AutoIncGet) then u8ArrIndexGetActual += <length>	VLD(al [<index>], <length>) (Issued only one time)	
226, xE2	<value>		Get last set EEPROM address <value>=u32EptrSet		
227, xE3	<value>		Get actual EEPROM address setting in PROFIBUS interface <value>=u32EptrActual		
228, xE4	<value>	GET_NET_LOST_LABEL	<value>=u16NetLostLabel (initialized to the value of u16NetLostLabelDefault during power-up)		
229, xE5	<value>	GET_NET_LOST_ACTION	<value>=u8NetLostAction (initialized to the value of u8NetLostActionDefault during power-up)	Upon loss of communication with PROFIBUS host, command is based on <value>:  0=IGNORE (No Command), 1=OFF (Motor Off), 2=X (Soft Stop), 3=S (Immediate Stop), 4=GOSUB, 5=GOTO	
230, xE6	<value>	GET_POLL_RATE	<value>=u32PollRate Rate at which SmartMotor is polled by PROFIBUS (initialized to the value read from SmartMotor EEPROM location 32012 during power up)		
231, xE7	<value>	GET_NET_LOST_LABEL_DEFAULT	<value>=u16NetLostLabelDefault (saved in nonvolatile storage in the SmartMotor)		
232, xE8	<value>	GET_NET_LOST_ACTION_DEFAULT	<value>=u8NetLostActionDefault (saved in nonvolatile storage in the SmartMotor)	Upon loss of communication with PROFIBUS host, command is based on <value>:  0=IGNORE (No Command), 1=OFF (Motor Off), 2=X (Soft Stop), 3=S (Immediate Stop), 4=GOSUB, 5=GOTO	
233, xE9	<value>	GET_NET_DEVICE_ID	<value>=u32NetDeviceId (saved in nonvolatile storage in the SmartMotor)	RCADDR	



## Response Packet Codes to Motor Commands

Response Code	Response Data Value	Note	Response Description	Smart Motor Command(s)	Smart Motor Response
<i>decimal, hex</i>					
234, xEA		Reserved			
235, xEB	<value>	GET_ENC_RESOLUTION	<value>=s32EncResolution (read at startup from SmartMotor EEPROM location 32000)	RRES	
236, xEC	<value>	GET_FIRMWARE_VERSION	<value>=u32FirmwareVersion (read at startup with RSP)	RFW	
237, xED		Reserved			
238, xEE	<value>	GET_SAMPLE_RATE	<value>=s32SampleRate (read at startup with RSP)		
239, xEF	<value>	GET_MOTOR_ID	<value>=u32MotorId (read at startup from SmartMotor EEPROM location 32016)		
240-254, xF0-xFE		Reserved			
255, xFF	<error code>	ERROR	Returned if the response code could not be performed successfully (<error code> values to be determined)		

# Troubleshooting

The following table provides troubleshooting information for solving SmartMotor problems that may be encountered when using PROFIBUS. For additional support resources, see the Moog Animatics Support page at:

<http://www.animatics.com/support.html>

Issue	Cause	Solution
<b>PROFIBUS Communication Issues</b>		
<b>NOTE:</b> Auto-detect of master's PROFIBUS baud rate may take 5 to 10 seconds after SmartMotor power up. PROFIBUS master repeatedly sends the "are you there?" command packet. Slave motor does not transmit on PROFIBUS unless commanded to answer by the master.		
No PROFIBUS connection. The PROFIBUS connection status LED is off after power up and while connected to the master.	Motor not powered. Drive Status LED is off and/or PROFIBUS status LED is off.	Check Drive Status LED. If LED is not lit, check wiring.  If only the PROFIBUS status LED is off, connection to PROFIBUS Host, or watchdog expired. Verify that host is communicating to the MACID set for this motor.
	Disconnected or miswired connector, or broken wiring between slave and master.	Check that connectors are correctly wired and connected to motor. For details, see PROFIBUS Motor Connectors and Pinouts on page 18.  Check that oscilloscope shows good square 3v signals.  Check that PROFIBUS A and B signals are not reversed.
	Motor nonvolatile settings.	Check that motor MACID has been set to the value expected by the host PLC.  Check that polling rate is set to 0, which allows fastest response.
	Wrong type of cable.	Check that cable is a PROFIBUS cable. For details, see Cables and Diagram on page 19.
	Wrong GSD file.	Verify that the correct GSD file was used to configure the master and connect the slave motor as part of the PROFIBUS network.
	Terminator and bias resistors are not correct.	Check that terminators are at each end of the bus, and each terminator's total resistance is 110 ohms.  If using PROFIBUS connectors with built-in terminators, check that the switches are ON at each end of the bus only, and all other terminator switches on the bus must be OFF.

Issue	Cause	Solution
<b>Other Communication and Control Issues</b>		
Motor does not communicate with SMI.	Transmit, receive, or ground pins are not connected correctly.	Ensure that transmit, receive and ground are all connected properly to the host PC.
	Motor program is stuck in a continuous loop or is disabling communications.	To prevent the program from running on power up, use the Communications Lockup Wizard located on the SMI software Communications menu.
Motor disconnects from SMI sporadically.	COM port buffer settings are too high.	Adjust the COM port buffer settings to their lowest values.
	Poor connection on serial cable.	Check the serial cable connections and/or replace it.
	Power supply unit (PSU) brownout.	PSU may be too high-precision and/or undersized for the application, which causes it to brown-out during motion. Make moves less aggressive, increase PSU size, or change to a linear unregulated power supply.
After power reset, motor stops communicating over serial port, requires re-detection.	Motor does not have its address set in the user program. NOTE: Serial addresses are lost when motor power is off or reset.	Use the SADDR or ADDR= command within the program to set the motor address.
Red PWR SERVO light illuminated.	Critical fault.	To discover the source of the fault, use the Motor View tool located on the SMI software Tools menu.
<b>Common Faults</b>		
Bus voltage fault.	Bus voltage is either too high or too low for operation.	Check servo bus voltage.
Overcurrent occurred.	Motor intermittently drew more than its rated level of current. Does not cease motion	Consider making motion less abrupt with softer tuning parameters or acceleration profiles.
Excessive temperature fault.	Motor has exceeded temperature limit of 85°C. Motor will remain unresponsive until it cools down below 80°C.	Motor may be undersized or ambient temperature is too high. Consider adding heat sinks or forced air cooling to the system.
Excessive position error.	The motor's commanded position and actual position differ by more than the user-supplied error limit.	Increase error limit, decrease load, or make movement less aggressive.
Historical positive/negative hardware limit faults.	A limit switch was tripped in the past.	Clear errors with the ZS command.
	Motor does not have limit switches attached.	Configure the motor to be used without limit switches by setting their inputs as general use.

<b>Issue</b>	<b>Cause</b>	<b>Solution</b>
<b>Programming and SMI Issues</b>		
Several commands not recognized during compiling.	Compiler default firmware version set incorrectly.	Use the "Compiler default firmware version option" in the SMI software Compile menu to select the default firmware version closest to the motor firmware version. In the SMI software, view the motor firmware version by right-clicking the motor and selecting Properties.



**PN: SC80100009-001**  
**Rev. A**